


Controller TS-S2 ► 592 TS-SH ► 592 TS-SD ► 602

TS-S2 ► 592 | TS-SH ► 592 | TS-SD ► 602 | Controller



M4×0.7 Depth 5 (For securing cable)

SRD04 Space-saving model (motor installed on top)

Option: Horizontal installation plate (foot)


Contents of option: Plate, 2 pcs., Nut, 12 pcs See our robot manuals for additional settings

SRD04

Robonit

single-axis robots

INFORMATIO



Note 1. It is possible to apply only the axial load.

Use the external guide together so that any radial load is not applied to the rod. Note 2. The orientation of the width across flat part is undefined to the base surface.