

Point data item list

P1 to P255		
Item	Description	
1	RUN type	Specifies the positioning operation pattern.
2	Position	Specifies the positioning target position or movement amount.
3	Speed	Specifies the positioning speed.
4	Accel.	Specifies the positioning acceleration.
5	Decel.	Specifies the positioning deceleration (as a percentage of the acceleration).
6	Push	Specifies the electrical current limit value for “Push” operations.
7	Zone (-)	Specifies the “personal zone” output range.
8	Zone (+)	
9	Near width	Specifies the “near width” zone (distance tolerance relative to target position).
10	Jump	Specifies the next movement destination, or the next merge operation merge destination point No. following positioning completion.
11	Flag	Specifies other information related to the positioning operation.
12	Timer	Specifies the waiting time (delay) after positioning completion.

“Standard setting” and “custom setting”

There are 2 setting types for point data (“standard setting” or “custom setting”). Select the desired setting type according to the application. The maximum number of setting points for both setting types is 255 points (P1 to P255).

Setting Type	Description
Standard setting	Optimum positioning is provided simply by specifying the payload. This setting type is well-suited to assembly and transport applications.
Custom setting	Allows changing the speed and acceleration in SI units so the desired positioning operation can be set. This setting type is suited for machining and inspection systems.