AGXS20

Advanced model Single-axis robots Slider type

■ Ordering method						
AGXS20-				- EP- 01-]-	-
Model – Lead Shape	Motor specification	Stroke - Ca	Note 1 Cable entry location	Robot Driver:	Regenerative unit	I/O
40: 40 mm S: Straight	S: Standard/With no brake	100 to 1450 R3	3: 3 m R: From rear	EP-01 A30:	No entry: None	EP: EtherNet/I
20: 20 mm R: Right bending	BK: Standard/With brake	(50mm pitch) R	5: 5 m of motor	400W/750W	R: With EP-RU	PT: PROFINET
10: 10 mm L: Left bending	BL: Battery-less absolute/	R1	10: 10 m F: From front			ES: EtherCAT
	With no brake		of motor			NS: NPN
	DIVIDI D II I I I I I					00.001:-1

Note 1. The robot cable is flexible and resists bending. Note 2. When the actuator is used vertically, the regenerative unit is needed.

When the actuator is used horizontally and the stroke of lead 20 is 400 to 850 mm or the stroke of lead 40 is 600 to 950 mm, the regenerative unit is needed. Note 3. When the motor specification is the standard (S, BK), whether to use the battery needs to be selected.

Specification	าร										
AC servo motor output			750 W								
Repeatability Note 1		+/-0.005 mm									
Deceleration mechanis	m	Ground ball screw φ 20 (C5 class)									
Stroke		100 mm to 1450 mm(50 mm pitch)									
Maximum speed Note 2		2400 mm/sec	1200 mm/sec	600 mm/sec							
Ball screw lead		40 mm	20 mm	10 mm							
Maximum payload	Horizontal	65 kg	130 kg	160 kg							
maximum payloau	Vertical	15 kg	35 kg	65 kg							
Rated thrust		320 N	640 N	1280 N							
Maximum dimensions e section of main unit	of cross	W 2	200 mm × H 140	mm							
Overall length	Straight		ST + 390.8 mm								
Overall leligtii	Bending		ST + 340.5 mm								
Degree of cleanliness N	lote 3	ISO C	CLASS 3 (ISO146 or equivalent	344-1)							
Intake air Note 4		30	Ne/min to 90 Ne/i	min							
Position detector			Absolute encode y-less absolute e								
Resolution			23 bits								
Using ambient tempera humidity	ature and	0 to 40 °C, 35 to 80 %RH (non-condensing)									

Note 1. Positioning repeatability in one direction. Note 2. When a moving distance is short and depending on an operation condition, it

may not reach the maximum speed.

If the effective stroke exceeds 800 mm, the ball screw may resonate. (Critical

speed)
At this time, make the adjustment to decrease the speed while referring to the maximum speed shown in the table.


Note 3. When using in a clean environment, attach a suction air joint. The degree of


cleanliness is the cleanliness level achieved when using at 1000 mm/sec or

Note 4. The required suction amount will vary according to the operating conditions and operating environment.

Note. See P.133 for acceleration/deceleration.

■ Allowable overhang







AGXS2 Horizont		llation	(Unit: mm)	Wall in:	stallati	on (Unit: mm)	Vertical in	stallation	(Unit: mm)
	Α	В	С		Α	В	С		Α	С
20kg	5318	2821	2096	20kg	2171	2751	5211	5kg	8187	8187
40kg	4836	1609	1369	40kg	1417	1539	4667	10kg	5203	5203
65kg	4824	1088	1001	65kg	1013	1018	4575	15kg	4810	4810

AGXS2	0-20									
Horizont	al insta	llation	(Unit: mm)	Wall in	stallati	on (Jnit: mm)	Vertical in	stallation	(Unit: mm)
	Α	В	С		Α	В	С		Α	С
50kg	5436	1493	1377	50kg	1390	1423	5265	20kg	3436	3436
80kg	4417	911	854	80kg	849	841	4153	30kg	2600	2600
100kg	4592	756	727	100kg	708	686	4253	35kg	3073	3073
130kg	4338	596	584	130kg	550	526	3933			


Α	GXS2	0-10									
Н	orizont	tal instal	lation	(Unit: mm)	Wall in:	stallati	on (Unit: mm)	Vertical in	stallation	(Unit: mm)
		Α	В	С		Α	В	С		Α	С
	40kg	22519	2607	2713	40kg	2704	2537	22210	20kg	5157	5157
	80kg	16716	1274	1331	80kg	1293	1204	16141	40kg	2553	2553
	120kg	14066	830	868	120kg	818	760	13223	65kg	1600	1600
	160kg	12284	608	637	160kg	580	538	11190			

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

Note. Service life is calculated for 600 mm stroke models

■ Controller Controller Operation method EP-01 I/O point trace/Remote command


■Static loading moment





		(Unit: N·m)
MY	MP	MR
1423	1423	1251



▶ The cycle time simulation and service life calculation can be performed easily from our member site. For details, see P.12.







- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. When changing the return-to-origin direction, the parameter needs to be changed. (The standard is that the origin is located on the motor side.)
- Note 3. The length under head of the hex socket head bolts <M8 × 1.25 used to mount the body with the mounting counterbore holes (section C cross-section) must be <<25 mm or more>. The recommended length under head of the hex socket head bolts <M8 × 1.25 > used to mount the body with the mounting tap hole specifications is <<fr>
- Note 4. When using the mounting counterbore holes (section C cross-section) to mount the body, remove the seal, and then fix.

 Note 5. Weight without brake. The weight with the brake is 1.1 kg heavier than the value
- in the weight column.

 Note 6. The robot cable is extracted from the front.


 Note 7. The robot cable is extracted from the rear.

Note 10. The fixed minimum bending radius of the robot cable is R30.

When using the robot cable as a flexible cable, use it with a minimum bending radius of R50 or more.

Note 11.Grease gun nozzle (recommended) (see P.143 for detail)

Effecti	ve stroke	100	150	200	250	300																							
	La	490.8	540.8	590.8	640.8	690.8	740.8	790.8	840.8	890.8	940.8	990.8	1040.8	1090.8	1140.8	1190.8	1240.8	1290.8	1340.8	1390.8	1440.8	1490.8	1540.8	1590.8	1640.8	1690.8	1740.8	1790.8	1840.8
	Lb	388.5	438.5	488.5	538.5	588.5	638.5	688.5	738.5	788.5	838.5	888.5	938.5	988.5	1038.5	1088.5	1138.5	1188.5	1238.5	1288.5	1338.5	1388.5	1438.5	1488.5	1538.5	1588.5	1638.5	1688.5	1738.5
	Lc	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450
	Ld	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200
	Qa	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18	18	20	20	20	20	22	22	22	22
	Qb	4	6	6	6	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18
	Qc	0	0	0	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6	6
	Qd	0	0	0	0	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6
Weight	(kg) Note 5	19.1	20.4	21.7	23.0	24.3	25.6	26.9	28.2	29.5	30.7	32.0	33.3	34.6	35.9	37.2	38.5	39.8	41.1	42.3	43.6	44.9	46.2	47.5	48.8	50.1	51.4	52.7	53.9
Manufactura	Lead 40								2400								2160	1920	1680	1440	1320	1200	1080	96	30	840	72	20	600
Maximum	Lead 20		1200													1080	960	840	720	660	600	540	48	30	420	36	30	300	
speed (mm/sec)	Speed Lead 10 600												540	480	420	360	330	300	270	24	10	210 180		30	150				
(IIIIII/Sec)	Speed setting								_								90%	80%	70%	60%	55%	50%	45%	40	%	35%	30	%	25%
$\overline{}$																													



- Note 1. Stop positions are determined by the mechanical stoppers at both ends
- Note 2. When changing the return-to-origin direction, the parameter needs to be changed. (The standard is that the origin is located on the motor side.)
- Note 3. The length under head of the hex socket head bolts <M8 × 1.25> used to mount the body with the mounting counterbore holes (section C cross-section) must be <<25 mm or more>>. The recommended length under head of the hex socket head bolts <M8 × 1.25> used to mount the body with the mounting tap hole specifications is <<frame thickness + 15 mm or less>>.

 Note 4. When using the mounting counterbore holes (section C cross-section) to mount
- the body, remove the seal, and then fix.

 Note 5. Weight without brake. The weight with the brake is 1.1 kg heavier than the value
- in the weight column.

 Note 6. The robot cable is extracted from the front.

 Note 7. The robot cable is extracted from the rear.

- Note 8. The robot cable (with brake) is extracted from the front.
- Note 9. The robot cable (with brake) is extracted from the rear.

 Note 10. The fixed minimum bending radius of the robot cable is R30. When using the
- robot cable as a flexible cable, use it with a minimum bending radius of R50 or
- Note 11. Grease gun nozzle (recommended) (see P.143 for detail)

Effective stroke	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450
La	440.5	490.5	540.5	590.5	640.5																				1640.5			
Lb	388.5	438.5	488.5	538.5	588.5	638.5	688.5	738.5	788.5	838.5	888.5	938.5	988.5	1038.5	1088.5	1138.5	1188.5	1238.5	1288.5	1338.5	1388.5	1438.5	1488.5	1538.5	1588.5	1638.5	1688.5	1738.5
Lc	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450
Ld	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200
Qa	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18	18	20	20	20	20	22	22	22	22
Qb	4	6	6	6	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18
Qc	0	0	0	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6	6
Qd	0	0	0	0	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6
Weight (kg) Note	21.8	23.1	24.4	25.7	27.0	28.3	29.6	30.9	32.2	33.4	34.7	36.0	37.3	38.6	39.9	41.2	42.5	43.8	45.0	46.3	47.6	48.9	50.2	51.5	52.8	54.1	55.4	56.6
Lead 4)	2400														2160	1920	1680	1440	1320	1200	1080	96	30	840	72	20	600
Maximum Lead 2)	1200												1080	960	840	720	660	600	540	48	30	420	36	30	300		
speed Lead 1)	600											540	480	420	360	330	300	270	24	10	210	18	30	150			
(mm/sec) Lead 1 Speed setti	ng	_											90%	80%	70%	60%	55%	50%	45%	40	%	35%	30)%	25%			