LCMR200

Product Lineup

LCM100 is introduced on another page. Features page P.22 Specifications page P.183

LINEAR CONVEYOR MODULES

Efficiency of time and space in production


Yamaha's answer to Next Generation of Production Line design




Linear conveyor module LCMR200




Note. As the figure shown above illustrates CG images, they are different from the actual product.




Advanced linear conveyor module with high speed transport.



From ordinary "passive flow" to "active position transport". By converting conveyor flow into active production process improves profitability.




Thorough comparison of LCMR200 and conventional conveyor



Superior performance that improves the transfer environment.

POINT 1


Transfer time is shortened to increase the production volume.



POINT 2

Easy modular connection with Connecting Plate and Connecting Unit


Mechanical connection by Connecting Plate and signal communicating by Connecting Unit. Simple yet, secured connecting method of modular system.





POINT 3

Saves space through proximity installation of forward and returning modules <Cable extraction direction can be selected Front Rear >

Since the cable extraction direction of a module can be selected, the degree of freedom in electrical wiring is improved when installed on the equipment. In particular, when the cable extraction direction is reversed on the forward and returning modules in the horizontal circulation layout, the module pitch can be made close to the shortest level of 200 mm. This can shorten the cycle time and reduce the installation space during circulation. In addition, the LED indicators that show the module state can be visually checked from both the front and rear sides of the module.







POINT 4

All the sliders can be operated / programmed independently.

Speed and acceleration can be programmed by each move. All carriages can be controller individually.



POINT 5

Top enclosure design for protection.

Top enclosure was designed to protect internal mechanism from any fallen object during line setup process.



POINT 6

Mechanical tolerance between sliders +/-30 µm (Dowel hole standard)

Due to tis machined accuracy, each carriage has own tolerance at one stopping point, however, LCMR200 can limit the slide machine difference to \pm -30 μ m, and is suitable for high precision process. As RFID, etc. is not necessary, cost reduction is possible.

POINT 7

No origin process needed

Newly developed high-precision full-range absolute server eliminates the need for return-to-origin. The operation can be started and stopped easily, so there is no time loss even when starting or restarting.

High acceleration rate

High speed motion between an extremely short distance is possible even in a high density process or pitch feed.


Recognize slider's individual IDs

All sliders can be identified when the power is applied.

POINT 8

Low profile structure


By adopting a newly developed linear motor, the module height is approx. 30 % down compared to LCM100. The space under the frame can be effectively utilized.




POINT 9

Built-in driver saves electrical wiring

Motor driver is incorporated inside module and entire LCMR200 is controlled by YHX controller through YQLink cable. It also contributes to space saving inside the control panel.





POINT 10

Concentrated control by the YHX controller

Including the operation environment, all sliders and single-axis robots on the transfer process can be controlled.

POINT 11

Simple control with the standard profile

According to the commands from the host PLC, it adopts a simple control method that operates the sliders and single-axis robots as positioners

Features of YHX standard profile Details P.610

- Eliminates writing ladder logic codes.
- Adding operation through a pendant.
- Perform simple direct value operation and specific point-to-point move.
- Servo ON of any slider individually.
- Obtain alarm information through the host PLC.



Versatile and value added transport between work process.

Improve cycle time and reduce line floor space. Increase productivity and cost performance.










POINT 12






Process sharing

- Carriage is bi-directional and one work station can perform more than one task. Saving total line cost and floor space.
- High speed bi-directional move and simultaneous independent operation of multiple carriages.





POINT 13

Direct drive Narrow pitch operation









Variable speed control between work stations.


- Servo controlled direct drive eliminates mechanical stoppers and position sensors.
- Simple position setting by entering point data in a program.
- Flexibility in setup for production lot change
- Saving flow time by narrow pitch incremental move and high speed move.



Assembly can be done while parts are on conveyor.

- The highly rigid guide enables assembly and processing on the transport line.
- No need to reposition parts to/from conveyor. Floor line space is reduced substantially.





POINT 15

Easily serviceability = Easy troubleshooting


- Covered structure of module keeps internal mechanism free from foreign objects.
- The environment-resistant magnetic sensor is resilient to contamination.
- Easy positioning with no precision setting.
- Non-contact motor and linear scale design eliminates mechanical wearing.
- Low particle generation (only mechanical contact is guide rail)
- Standardized components reduce spare parts SKU.
- Parts can be replaced easily.
- Operation can be restored just by replacing the slider or linear module, and the manufacturing line down time can be kept to a minimum.


Sleek and simple configuration. Simplified line design process with flexibility and efficiency by modular concept.

All carriages and peripheral linear robots can be controlled by PLC through one YHX controller.

POINT 16

Layout example with a combination of the module and circulation unit.






Circulation unit

Horizontal circulation unit / Vertical circulation unit

Circulation units are available as standard.

Because the circulation units are manufacturer's standard products, the stable operation of the production line is achieved without worrying about module "deviation". Furthermore, you can also save time and effort in design.

YAMAHA genuine circulation units achieve the stable operation of the production line.



(For positioning of the module on the main line side)


Junction axis


POINT 1


Measures against "deviation" necessary to maintain the accuracy are taken thoroughly.

Maintaining the accuracy is very important for transfer sections, but is not easy since "deviation" may occur.

Use of YAMAHA genuine circulation units makes it possible to eliminate such "deviation" and maintain the accuracy.








POINT 2

Easy adjustment

The adjustment has been performed before shipment from the factory. After the product has been arrived, the adjustment is completed in a short time by simply attaching the module to the equipment based on the end plate and performing the teaching.



LCM100

Product Lineup

LCM200 is introduced on another page.

Features page P.12

Specifications page P.159


LINEAR CONVEYOR MODULES

From "flow" to "move"

Efficient transfer processes for increased profitability



Linear Conveyor Module LCM100 Constructing high-speed throughput lines.




Note. The positioning accuracy for a standardie sider when positioning from one direction (single-side approach).

Note. The positioning accuracy for the single-side approach after correction by RFID is 0.1 mm including

the mutual difference between sliders.

POINT

Increase productivity by shortening transport time





The length of the transfer line can be adjusted freely by adding modules.

POINT

Save equipment space.

- Since the movement direction can be changed, the same processes are made common. This makes the equipment compact and results in cost reduction.
- Forward and backward movement at a high speed can be set freely.
- Flexible actions such as moving only some sliders backward is possible.






POINT

Can be moved efficiently between processes with different tacts


- Narrow pitch movement is possible.
- Movement time can be reduced by combining the use of different movements, such as using pitch-feed for the same processes in shorttime processes while transferring three workpieces at the same time at a high speed in long-time processes.




POINT

Workpieces do not need to be retracted

- As the work moves down, you can assemble and process them on the transfer line.
- Eliminates having to retract the work from the pallet to the work table.
- Reduces costs.






POINT

Significant reduction of start-up time


- Just connect modules for easy construction of a transfer line.
- Lifting cylinders, sensors, stoppers, and other complex parts are not necessary.
- Operations can be performed by using only the LCC140 Controller.
- Economical as excess modules can be used for other lines or stored for maintenance.





POINT

Construct branching lines, joint lines, and other lines in flexible configurations.

Layout examples by combining modules with circulation mechanisms









Note. The customer needs to prepare the return unit and the circulation mechanism. Note. Modules convenient for the circulation are configured.

POINT


Optimal for small batch production of various product types

- No need for mechanical stoppers or sensors. Change layout easily.
- Reconstruction can be finished quickly by just changing the program to set a stop position.
- Frequent unit changes for different models can be handled flexibly.





Flexible set-up of the slider's acceleration/deceleration, forward/backward movement, positioning, and other actions. The variety of possible line structures has been greatly expanded to supersede conventional models.



POINT

Quick recovery by replacing the slider when machine trouble occurs

- Parts can be replaced easily.
- Parts can be kept for maintenance as they are standardized.
- Possible to minimize the downtime of a production line.






POINT

Easy maintenance


- Motors and scales do not make contact and are free from abrasion.
- As only the rails are sliding parts, dust generation is low.
- There are only a few consumable parts, which mean a long service life.



System configuration diagram (when 3 sliders are connected)



Belt module



This interface allows the customer to supply 24V power and select just the necessary signals to use. Note. The customer will need to prepare the wiring on the user side.

Linear module controller LCC140



Program operation

The LCC140 controller can perform operations using registered programs and operations using remote commands from the PLC.

In addition to the control of input/output signals such as movement or positioning, processes related to the insertion/ejection of sliders can be performed.

Controller-linking function

You can use the link cables dedicated to LCC140 controllers to connect the controllers when two or more modules are connected. You can handle multiple controllers as if they were one controller.

SR1 controller base operation system


The same user interface as the SR1 controller is incorporated, and specifications and functions specific to the linear conveyor module have been added based on this user interface. A very user friendly operation system is provided. Note 1

Position correction function using RFID

When multiple sliders are each stopped at a position of your choice, actual stop positions has an error width (machine difference) of 500 $\mu m.$ This is because each slider has a different stopping accuracy. Link the RFID unit and LCC140 controller to suppress the machine difference of individual sliders to an error width of approximately 100 $\mu m.^{\text{Note 2}}$

Note 1. Please note that some Yamaha single-axis controller SR1 functions are not available with the linear conveyor controller

Note 2. All sliders stop within the width of 100 μ m that includes a teaching point.



LINEAR CONVEYOR MODULES

LCMR200

CONTENTS

■ LCMR200 basic specifications ···16
■ Allowable Load ······16
■ Configuration parts ······16
■ External view ······16
■ Circulation unit Order model …16
■ Circulation unit Basic specifications ······16
■ Circulation unit options ·····16
■ Circulation unit External view · · · 17

LCMR200 basic specifications

LCMR200 basic specifications

Drive method		Linear motor with moving magnet type core
Position Search		Magnetic absolute position sensor
Maximum payload		15 kg
Maximum speed		2,500 mm/sec *1
Repeatability		+/-5 μm
Mechanical tolerance be	etween robot sliders	+/-30 µm (Dowel hole standard)
Total stroke limit		25.5 m ^{*2}
Maximum number of rol	oot sliders	64 units *2
Minimum spacing between	een robot sliders	210 mm *3
Main frame dimensions	Max. external size of frame cross-section	W175 × H109 mm (Including robot slider)
Wall hame alliensions	Linear module length	200 mm / 300 mm / 500 mm / 1000 mm
	Robot slider length	198 mm
Weight	Linear module	Approx 20 kg [Per 1 m of linear module]
vveigni	Robot slider	2.4 kg
Power supply	Control power supply	48 VDC Required power [W] = 75 [W/m] x Overall length of module [m] '4
Motor power supply		48 VDC Yamaha's designated model '5
	Operating temperature	0 °C to 40 °C *6
Operating environment	Storage temperature	-10 °C to 65 °C
	Operating humidity	35 % to 85 %RH [No condensation]
Controller		YHX controller *7

- *1. When the conveying weight exceeds 10 kg, it will drop to 2,000 mm/sec according to the weight. *2. It may differ depending on the system configuration.
- $^{\star}3$. When the jig palette to equip to the robot slider is longer, it shall be the jig palette length + 10 mm.
- $^{\star}4.$ The option 600 W power source supplies the power to the linear module with a length of up to 8 m $\,$ while the 1000 W power source supplies the power to the linear module with a length of up to 13.3 m. *5. The option power source can supply the power to up to two robot sliders.
- (When AC 200 to 240 V is input.)
- *6. Operate LCMR200 in the temperature environment (+/-5 °C) that installation and adjustment were
- *7. The YHX controller requires a separate electrical power supply.


Static loading moment

Static load	ding mome	nt [N·m]	MY (1)			
MP	MY	MR				
47.0	35.7	31.4				
MR						
MP						

Allowable overhang

payload	Allowable overhang [mm]		
[kg]	Α	В	С
5	760	405	239
10	762	231	158
15	700	173	122

* Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.



Allowable Load

Note. • When center of slider is center of gravity.

• Allowable load in the moving direction of slider is always 28 N regardless of the loading position.

Load: Horizontal Direction

Payload: Common up to 15 kg.

Loading Position		L	oading Pos	ition Z [mn	n]	
X [mm]	0	20	40	60	80	100
0	611	514	443	390	348	314
20	517	445	391	349	315	287
40	447	393	350	316	288	264
60	394	352	317	289	265	245
80	353	318	289	266	245	228
100	319	290	266	246	229	214

Unit: [N]

Load: Vertical Direction



Loading Position		L	oading Pos	ition Y [mr	n]	
X [mm]	0	20	40	60	80	100
0	924	687	546	453	387	339
20	760	593	485	411	356	314
40	647	521	436	375	328	293
60	562	465	396	345	305	274
80	498	420	362	319	285	258
100	446	382	335	297	268	243

Payload: 10 kg


Loading Position	Loading Position Y [mm]					
X [mm]	0	20	40	60	80	100
0	874	650	517	429	367	320
20	721	561	459	389	337	297
40	613	493	413	355	311	277
60	533	440	375	327	289	260
80	471	397	343	303	270	244
100	423	362	317	282	254	231

Payload: 15 kg

Loading Position		Lo	oading Pos	ition Y [mn	n]	
X [mm]	0	20	40	60	80	100
0	826	614	488	406	347	303
20	680	529	433	367	318	281
40	578	466	390	335	294	261
60	503	416	354	309	273	245
80	445	375	324	285	255	231
100	399	342	299	266	239	217

Unit: [N]

Configuration parts



* The direction for the order of the driver numbers. The motor power source connector is attached to the module.

Robot slider		and a
Model	LCM200-XBOT-****	4
Parts No.	KNA-M2264-**	

When ordering the robot slider, specify slider ID number 1001 to 1139 in the last 4 digits " section of the model.

ID, m			
ID	Model	Parts No.*	
1001	LCMR200-XBOT-1001	KNA-M2264-01	
1002	LCMR200-XBOT-1002	KNA-M2264-02	
1099	LCMR200-XBOT-1099	KNA-M2264-99	ID 110s are A*.
1100	LCMR200-XBOT-1100	KNA-M2264-A0	ID 111s are B*. ID 112s are C*.
1112	LCMR200-XBOT-1112	KNA-M2264-B2	ID 1123 are D*.

YQLink cable

YQLink movable cable

Refer to the system configuration drawing for a connection example.



Cable length	Model	Parts No.
0.3m	YHX-YQL-R0.3M	KFA-M5361-P1
3m	YHX-YQL-R3M	KFA-M5361-31
7m	YHX-YQL-R7M	KFA-M5361-71
10m	YHX-YQL-R10M-N	KFA-M5361-A1

YQLink fixation cable						
Cable length	Model	Parts No.				
15m	YHX-YQL-M15M	KNA-M5362-F0				

YQLink terminating connector	
Model	Parts No.
YHX-YQL-TC	KFA-M5361-00

Other power source options

Module electric power supply (48 VDC)

Unit type general purpose power supply corresponding to the peak output that is applicable to both the module control and motor power. Select a power supply suitable for the required power and equipment installation conditions by considering the supply capacity and outside dimensions per application of each power supply.





LCM-XCU-PS-1000W

- Rated output 600 W/1000 W, Efficiency > 80%, Power factor > 90%
- When AC 200 to 240 V is input, the peak maximum output is 42 A (within 5 seconds).

Supply capacity			
	Motor power supply [Peak maximum output]		Parts No.
Cluster within 8m [600W]	Within 2 sliders [1992W]	PS-48V-600W	KNA-M6561-00
Cluster within 13.3 m [1000W]	Within 2 sliders [2016W]	LCM-XCU-PS-1000W	KFA-M6561-00

Flexible power cable for movable module	
Model	Parts No.
LCMR200-PJ-R2M	KNA-M539H-21

LCMR200 Connection Parts

Module conne	ection kit	
Model	Parts No.	Configuration parts
LCMR200-CKIT	KNA-M2043-C0	Connection unit Connection plate Motor power source jumper Control power source jumper

Module termi	nal kit*	
Model	Parts No.	Configuration parts
LCMR200-EKIT	KNA-M2043-E0	End unit ×2 End plate ×2 Control power supply connector

* When a circulation unit made by Yamaha is not used, one terminal kit is necessary for one cluster. The components for two terminal kits are assembled to or supplied with Yamaha circulation unit.

Adjuster kit*		To a
Model	Parts No.	Configuration parts
LCMR200-AKIT	KNA-M2043-A0	Connection unit Adjuster plate Motor power source jumper Control power source jumper

Return line length	Number of adjuster kit
3 m or less	1
More than 3 m and 14 m or less	2
More than 14 m and 25.5 m or less	3

For the return line, use the specified number of adjuster kit according to the return line length.
For details about the usage location and how to use, see the user's manual.

Maintenance items*

Control power supply connec	ctor
Model	Parts No.
LCMR200-CPC	KNA-M4431-00

Control power source jumper	
Model	Parts No.
LCMB200-CP.I	KNA-M4421-10

Motor power source connect	or
Model	Parts No.
LCMR200-MPC	KNA-M4432-00

Motor power source jumper	1
Model	Parts No.
LCMR200-MPJ	KNA-M4422-10
LCMR200-MPJS (for 1000 mm module relay)	KNA-M4422-20

End plate	200
Model	Parts No.
LCMR200-EP	KNA-M22GM-E0
	4

Connection plate	****
Model	Parts No.
LCMR200-CP	KNA-M22GM-C0

Adjuster plate	
Model	Parts No.
LCMR200-AP	KNA-M22GM-A0
_	

End unit	
Model	Parts No.
LCMR200-EU	KNA-M2040-E0

Connection unit	
Model	Parts No.
LCMR200-CU	KNA-M2040-C0


^{*}These are single models of parts included in the module connection kit, adjuster kit, module terminal kit, circulation unit, or module main body.


External view

LCMR200 Module connection and installation


Front* cable extraction

LCMR200-F**






Module type	LA	LB
LCMR200-F2	199.4	183
LCMR200-F3	299.4	283
LCMR200-F5	499.4	483
LCMR200-F10	999.4	983




Linear module


Front* cable extraction

LCMR200-F2



LCMR200-F3 12-φ6.2 through-hole φ10 spot facing depth 5.2(Note 10) 299.4 24.7 50 . 50 . 50 . 50 . 50 Front line Front line 132 43 \ Front line





- Note 1. The robot slider unstoppable range of 99 mm from both ends of the cluster may vary depending on the pallet length. However, when there is no adjacent cluster, the robot slider unstoppable range is 90 mm regardless of the pallet length. For details, see the manual.

 Note 2. Module types can be freely combined within the same cluster after the front and rear of the cable extraction direction have been aligned.

 Note 3. The control power source and motor power source can be passed and received by the jumper connector. See the manual for detail of passing and receiving.

 Note 4. For the YGLink cable and YQLink terminating connector connection location, see the manual.

 Note 5. Sixty-four robot sliders can be installed in a system connected by the YQ Link cables "(depending on the number of robots that are controlled by the same controller).

 Note 6. Where modules are connected with the connection plate, the clearance between the adjacent modules is 0.6 mm.


 Note 7. The minimum pitch of each slider at the stopping state is 210 mm; however, when they start at the same time, they may collide due to operation conditions, and conditions such as command timing from the upper PLC, programming with YHX, etc. In the case, it is necessary to adjust by securing more distance (pitch) between the sliders, changing the start timing (sequential start), etc.
- The connection plate and connection unit are used to connect the modules, and the end plate and end unit are used at the cluster end.
- Note 10.To secure the module, end plate, connection plate, and adjuster plate to the base, use M5 hexagon socket head cap bolts.
- Note 11. Distance from the end plate reference surface, connection plate reference surface and adjuster plate reference surface to the spot facing hole for the module clamp bolt.

 Note 12. The YQLink movable cable is used. When the YQLink fixation cable is used, the distance is 104 mm.
- * It may differ depending on the system configuration.
 * Orientation corresponds to the order of the driver numbers


LCMR200 Module connection and installation

Rear* cable extraction

LCMR200-B**




Module type	LA	LB
LCMR200-B2	199.4	183
LCMR200-B3	299.4	283
LCMR200-B5	499.4	483
LCMR200-B10	999.4	983




Linear module


LCMR200-B2



LCMR200-B3




LCMR200-B5



Rear* cable extraction

LCMR200-B10



- Note 1. The robot slider unstoppable range of 99 mm from both ends of the cluster may vary depending on the pallet length. However, when there is no adjacent cluster, the robot slider unstoppable range is 90 mm regardless of the pallet length. For details, see the manual.
- regardless of the pallet length. For details, see the manual. Module types can be freely combined within the same cluster after the front and rear of the cable extraction direction have been aligned.

 The control power source and motor power source can be passed and received by the jumper connector. See the manual for detail of passing and receiving.

 For the YOLink cable and YOLink terminating connector connection location, see the manual. Sixty-four robot siders can be installed in a system connected by the YQ Link cables * (depending on the number of robots that are controlled by the same controller). Where modules are connected with the connection plate, the clearance between the adjacent modules is 0.6 mm.

- 0.6 mm.
 The minimum pitch of each slider at the stopping state is 210 mm; however, when they start at the same time, they may collide due to operation conditions, and conditions such as command timing from the upp PLC, programming with YHX, etc. In the case, it is necessary to adjust by securing more distance (pitch) between the sliders, changing the start timing (sequential start), etc.
 There is no mechanical stopper due to the nature of the product. Please install a mechanical stopper by the customer as needed
- the customer as needed.
- The connection plate and connection unit are used to connect the modules, and the end plate and end unit are used at the cluster end.
- Note 10. To secure the module, end plate, connection plate, and adjuster plate to the base, use M5 hexagon socket head cap bolts.
- Note 11. Distance from the end plate reference surface, connection plate reference surface and adjuster plate
- reference surface to the spot facing hole for the module clamp bolt.


 Note 12.The YQLink movable cable is used. When the YQLink fixation cable is used, the distance is 104 mm.
- * It may differ depending on the system configuration.
 * Orientation corresponds to the order of the driver numbers

External view

Robot slider LCMR200-XBOT 12.5 45 45 45 12-M5×0.8 Depth 10 8 66 500 Depth 8 25 110 110 1175


End plate

LCMR200-EP




Connection plate

LCMR200-CP



Adjuster plate


LCMR200-AP



Note 13. The overall length of the line after the modules have been connected using the adjuster plates can be adjusted. For details, see the manual.


End unit

LCMR200-EU



Connection unit

LCMR200-CU




YQLink movable cable

YHX-YQL-R□M (Only 10 m for R10M-N)


Within 🗆	Cable length			
0.3	0.3m			
3	3m			
7	7m			
10	10m	I		
(13.6)		(60) (35)	(ф8.8)	(35) (60) (39)

YQLink fixation cable

YHX-YQL-M15M




Flexible power cable for movable module




Control power supply connector / Motor power source connector

LCMR200-CPC/LCMR200-MPC



Module electric power supply (DC48V-600W)


PS-48V-600W



Note. M4 tap holes for installing the customer's chassis (8 locations)
(The maximum screw thread depth is 6 mm.)


Module electric power supply (DC48V-1000W)


LCM-XCU-PS-1000W




Circulation unit Order model


Horizontal circulation JGX16 20: 20mm R5 : 5m R: Right installation H2: Rear of motor S: Standard specification R: Rear of motor R10 : 10n LCMR200 **A30** YQI ink cable length (IN side) 3 YOLink cable length (OUT side) 3 B: With battery N: None F2: 200 mm (Front cable lead-out) 3: 3m 7: 7m 3: 3m 7: 7m N: None F3: 300 mm (Front cable lead-out) F5: 500 mm (Front cable lead-out) A: 10m A: 10m B2: 200 mm (Rear cable lead-out) T: Termination connector *2 B3: 300 mm (Rear cable lead-out) B5: 500 mm (Rear cable lead-out)





- Specify the same distance as that between the forward and backward movements
 of the equipment for the crculation pitch.
- The transfer cannot be stopped at a location other than the specified circulation pitch.
- After delivery, the customer cannot adjust the circulation pitch.
- The circulation pitch is selected at increments of 5 cm.
- *2 The termination connector can be selected only when the circulation installation position is R (right installation).
- $^{\star}3$ When the battery-less motor is selected, no battery is needed.





^{*} All illustrations shown above use the circulation installation position R (right installation).

Circulation unit Basic specifications

JGX16-H Basic specifications

■ JGX16-H Basic specifications

Axis configuration	Junction axis		LCMR200 *1
Motor output	80□ / 750W		-
Repeated positioning accuracy	+/- 0	.005	+/- 0.005
Speed reduction mechanism/drive method	Grinding ball screv	ν φ20 (C5 grade)	Linear motor with moving magnet type core
Ball screw lead	40mm	40mm 20mm	
Maximum speed *2	2400mm/sec 1200mm/sec		2500mm/sec
Circulation pitch/linear module length	200 to 800 mm (50 mm pitch)		200, 300, 500
Position detection	Magnetic type absolute position sensor *3		Magnetic type absolute position sensor
Operating temperature	0°C to 40°C '4		
Controller	YHX controller		

- * 1. For details about the specifications, see P.160.
 * 2. The maximum speed may not be reached depending on the operating range.
 * 3. The circulation transfer position only
 * 4. The operation is performed at an environmental temperature (+/-5 °C) at which the installation and adjustment have been performed.

■ JGX16-H Maximum payload per robot slider


Linear module length		200	300	50	00
Number of robot slider simultaneous circulations		1	1	1	1
Dell seren lead 1	40mm	15	15	15	12
Ball screw lead *1	20mm	15	15	15	15

*1 Note that the optimal lead length may vary depending on the operating environment.

■ JGX16-H Allowable overhang amount *1

Overhang direction		A direction	B direction	C direction *2
Number of robot slider simultaneous circulations		1 or 2	1 or 2	1 or 2
	5kg	760	405	239
Payload	10kg	762	231	158
	15kg	700	173	122

*1 Distance from the center of the top surface of the robot slider to the center of gravity of the load.



JGX16-V Basic specifications

■JGX16-V Basic specifications

Axis configuration	Junction axis		LCMR200 *1
Motor output	80□ / 750W		-
Repeated positioning accuracy	+/- 0	.005	+/- 0.005
Speed reduction mechanism/drive method	Grinding ball scre	w φ20 (C5 grade)	Linear motor with moving magnet type core
Ball screw lead	20mm 10mm		-
Maximum speed *2	1200mm/sec 600mm/sec		2500mm/sec
Circulation pitch/linear module length	300 to 600 mm (50 mm pitch)		200, 300, 500
Position detection	Magnetic type absolut	te position sensor '3	Magnetic type absolute position sensor
Operating temperature	0°C to 40°C *4		
Controller	YHX controller		

- * 1. For details about the specifications, see P.160.
 * 2. The maximum speed may not be reached depending on the operating range.
- * 3. The circulation transfer position only

 * 4. The operation is performed at an environmental temperature (+/-5 °C) at which the installation and adjustment have been performed.

■ JGX16-V Maximum payload per robot slider

Linear module length		200	300	50	00
Number of robot slider simultaneous circulations		1	1	1	2
Ball screw lead	20mm	15	15	15	10
	10mm	15	15	15	15


*1 Note that the optimal lead length may vary depending on the operating environment.

■ JGX16-V Allowable overhang amount *1

Overhang direction		A direction *2	B direction	C dire	ection					
Number of robot slider simultaneous	1 or 2	1 or 2	1	2						
	5kg	380	405	150	150					
Payload	10kg	380	231	150	100					
	15kg	380	173	122	50					

*1 Distance from the center of the top surface of the robot slider to the center of gravity of the load.

^{*2} When this unit is inserted or ejected to or from the lower stage line, the pallet height needs to be "circulation pitch - 220 mm" or less.



^{*2} Be aware that the robot sliders do not interfere with each other between the main lines.

Circulation unit Basic specifications


Transferrable pallet size list *1

	0:	Linear module	Р	allet length [mi	n]	Pa	allet width [mn	n]	Dellet herialet formal
	Circulation unit	length	А	В	A+B	С	D	C+D	Pallet height [mm]
		200	99	99	198				
	JGX16-H	300	199	199	298] No	ot restricted.*2		Not restricted.*2
Recommended size		500	399	399	498				
when one slider circulates.		200	99	99	198				
	JGX16-V	300	199	199	298	150	150	300	Circulation pitch - 220 mm
		500	399	399	498				
		200	99	99	198				
	JGX16-H	300	199	199	398	No	ot restricted.*2	Not restricted.*2	
Maximum size		500	399	399	798				
when one slider circulates.		200	99	99	198				
	JGX16-V	300	199	199	398	150	150	300	Circulation pitch - 220 mm
		500	399	399	798				
		200		Unavailable.			Unavailable.		Unavailable.
	JGX16-H	300		Oriavaliable.			Oriavaliable.		Oriavaliable.
Maximum size		500	145 *³	145 *3	244 *3	No	ot restricted.*2		Not restricted.*2
when two sliders circulate.		200		Unavailable.			Unavailable.		Unavailable.
	JGX16-V			Uriavaliable.			Uriavallable.	Unavallable.	
		500	145 ^{*3}	145 *³	244 *3	150	150	300	Circulation pitch - 220 mm

^{*1:} The pallet size indicates the total size of the loads on the robot slider including the customer's workpieces. In addition, it is assumed that all pallets on the robot sliders have the same shape.

For the horizontal circulation method, be aware that pallets or workpieces on the robot sliders that pass each other on the outbound and inbound routes do not collide with each other.

^{*3:} When either A or B is 122 mm or more, the pallet cannot be arranged at the center of the robot slider. It is assumed that all pallets on the robot sliders have the same shape.



^{*2:} The allowable overhang amount must not be exceeded. Be aware that the robot sliders do not collide with each other between the main lines.

Circulation unit options


JGX16 circulation accuracy measuring jig

Using this jig improves the workability when the following is measured.


- $\cdot \ \text{Teaching accuracy of the transfer section when YAMAHA genuine circulation unit is used.}$
- · Accuracy of the transfer section when the circulation part designed by the customer is used.
- · Installation accuracy of linear modules that are connected with the adjuster plate.

	YAMAHA horizontal circulation for JGX16-H	YAMAHA vertical circulation for JGX16-V	For circulation designed by the customer
Part number	S02J-M5360-202	S02J-M5360-102	S02J-M5360-004
Outside dimensions (Main body and measuring instrument are attached.)	W Approx. 250 mm x D Approx. 300 mm x H Approx. 150 mm	W Approx. 250 mm x D Approx. 300 mm x H Approx. 130 mm	W Approx. 250 mm x D Approx. 300 mm x H Approx. 150 mm
Main body weight (Measuring instrument is attached.)	Approx. 3.2 kg	Approx. 3.4 kg	Approx. 4.0 kg


YAMAHA horizontal circulation for JGX16-H (S02J-M5360-202)



For circulation designed by customer (S02J-M5360-004)




YAMAHA vertical circulation for JGX16-V (S02J-M5360-102)




- \cdot A (Side where there is front line.): Maintain at least 60 mm from the slider end.
- · B: Maintain at least 100 mm from the top of the slider.

If above spaces cannot be maintained, any part of the measuring jig may interfere with a peripheral device on the equipment side. Therefore, the measuring jig cannot be used on the linear module.

<Right figure direction explanation>






Circulation unit External view


Horizontal circulation

JGX16-H1L/H2L

JGX16-H1L


JGX16-H2L





(0.6: Clearance from module on main line side) 90 (Note 5), .99 (Note 5) 102.3 Base installation surface 160 D 100X | D70E120 109 5 (Sold separately.) 96 22 100 12.5 Grounding terminal (M4) 3:Clearance from base (Note 8)

2-slider circulation (Note 6)



Note 1. Note 2.

Note 3.

Note 4.

For details about the installation and operation procedures, see the user's manual.

The user wiring cannot be passed through the flexible cable carrier.

Do not use the installation hole at each location for an application other than that specified.

Movable module position when the junction axis is stopped by the mechanical stopper.

Robot slider unstoppable range from the module end.

An unstoppable range of 99 mm on the main line side may vary depending on the pallet length.

For details, see the Manual.

Two-slider simultaneous circulation can be performed only when the movable module is 500mm-module.

When the pallet length is 200 mm or more this pitch is "pallet length + 10 mm"

Note 6.

Note 7.

When the pallet length is 200 mm or more, this pitch is "pallet length + 10 mm".

However, when two sliders start at the same time, the minimum pitch is 250 mm or "pallet length + 50 mm".

Reference value for installation of the base. Install the circulation unit so that it is not in contact with the base end.


The robot cable fixing R is R30. The lead-out direction may vary depending on the specifications.


Note 9.

Note 10. The YQLink cable fixing R is R55. This cable may become the termination connector depending on the specifications. Note 11. The power cable fixing R is R55.

Note 12. The weight of the main body is a reference value. The weights of the module and robot slider are not included.

Circula	tion pitch	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350
I	La	639.5	689.5	739.5	789.5	839.5	889.5	939.5	989.5	1039.5	1089.5	1139.5	1189.5	1239.5	1289.5	1339.5	1389.5	1439.5	1489.5	1539.5	1589.5	1639.5	1689.5	1739.5	1789.5
ı	Lb	542.5	592.5	642.5	692.5	742.5	792.5	842.5	892.5	942.5	992.5	1042.5	1092.5	1142.5	1192.5	1242.5	1292.5	1342.5	1392.5	1442.5	1492.5	1542.5	1592.5	1642.5	1692.5
I	Lc	196.5	253.5	307.5	60.5	85.5	171.5	196.5	251.5	306.5	361.5	416.5	471.5	496.5	553.5	607.5	360.5	385.5	471.5	496.5	551.5	606.5	661.5	716.5	771.5
l	Ld	300	300	300	601	601	601	601	601	601	601	601	601	601	601	601	902	902	902	902	902	902	902	902	902
l	Le	356	356	356	356	356	356	356	356	356	356	356	356	356	366	366	366	366	366	366	366	366	366	366	366
	Qa	8	8	8	8	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16
	Qb	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
	Qc	2	2	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
Weight	(Kg) ^{Note 12}	27.6	28.7	31.7	33.6	34.7	35.8	37	38.1	39.3	40.4	41.6	42.7	43.9	45	46.2	48.1	49.3	50.4	51.6	52.7	53.9	55	56.2	57.3
Maximum	Lead 40							2400							2160	1920	1680	1440	1320	1200	1080	96	60	840	720
speed	Lead 20							1200							1080	960	840	720	660	600	540	48	30	420	360
(mm/sec)	Speed setting							-							90%	80%	70%	60%	55%	50%	45%	40)%	35%	30%






View A

Circulation unit External view


Horizontal circulation

JGX16-H1R/H2R


JGX16-H2R




JGX16-H1R



2-slider circulation (Note 6)





For details about the installation and operation procedures, see the user's manual.

Note 2.

Note 3.

Note 4.

The user wiring cannot be passed through the flexible cable carrier.

Do not use the installation hole at each location for an application other than that specified.

Movable module position when the junction axis is stopped by the mechanical stopper.

Robot slider unstoppable range from the module end.

An unstoppable range of 99 mm on the main line side may vary depending on the pallet length.

For details, see the Manual.

Note 6.

Note 7.

Two-slider simultaneous circulation can be performed only when the movable module is 500mm-module. When the pallet length is 200 mm or more, this pitch is "pallet length + 10 mm". However, when two sliders start at the same time, the minimum pitch is 250 mm or "pallet length + 50 mm".

Note 8. Reference value for installation of the base. Install the circulation unit so that it is not in contact with the base end.


Note 9. The robot cable fixing R is R30. The lead-out direction may vary depending on the specifications.


Note 10. The YQLink cable fixing R is R55. This cable may become the termination connector depending on the specifications.

Note 11. The power cable fixing R is R55.

Note 12. The weight of the main body is a reference value. The weights of the module and robot slider are not included.

Circulat	ion pitch	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350
L	_a	639.5	689.5	739.5	789.5	839.5	889.5	939.5	989.5	1039.5	1089.5	1139.5	1189.5	1239.5	1289.5	1339.5	1389.5	1439.5	1489.5	1539.5	1589.5	1639.5	1689.5	1739.5	1789.5
L	_b	542.5	592.5	642.5	692.5	742.5	792.5	842.5	892.5	942.5	992.5	1042.5	1092.5	1142.5	1192.5	1242.5	1292.5	1342.5	1392.5	1442.5	1492.5	1542.5	1592.5	1642.5	1692.5
L	_C	196.5	253.5	307.5	60.5	85.5	171.5	196.5	251.5	306.5	361.5	416.5	471.5	496.5	553.5	607.5	360.5	385.5	471.5	496.5	551.5	606.5	661.5	716.5	771.5
Į t	_d	300	300	300	601	601	601	601	601	601	601	601	601	601	601	601	902	902	902	902	902	902	902	902	902
L	_e	356	356	356	356	356	356	356	356	356	356	356	356	356	366	366	366	366	366	366	366	366	366	366	366
	Qα	8	8	8	8	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16	16
	Qb	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
	Qc	2	2	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4
Weight	(Kg) ^{Note 12}	27.6	28.7	31.7	33.6	34.7	35.8	37	38.1	39.3	40.4	41.6	42.7	43.9	45	46.2	48.1	49.3	50.4	51.6	52.7	53.9	55	56.2	57.3
Maximum	Lead 40							2400							2160	1920	1680	1440	1320	1200	1080	96	30	840	720
speed	Lead 20							1200							1080	960	840	720	660	600	540	48	30	420	360
(mm/sec)	Speed setting							-							90%	80%	70%	60%	55%	50%	45%	40	1%	35%	30%








Circulation unit External view


Vertical circulation

JGX16-V1L/V2L/V3L









- Note 1. For details about the installation and operation procedures, see the user's manual. Note 2. The user wiring cannot be passed through the flexible cable carrier.
- Note 3.
- Do not use the installation hole at each location for an application other than that specified. The robot cable fixing R is R30. The lead-out direction may vary depending on the specifications.
- The YQLink cable fixing R is R55. This cable may become the termination connector depending on the specifications.

 The power cable fixing R is R55. Note 5.
- Note 6.
- The weight of the main body is a reference value. The weights of the module and robot slider are not included.
- Note 8. Hexagon socket head cap bolt for fine adjustment of circulation pitch.
- Maintain a work space where you can access the bolt.
 - Robot slider unstoppable range from the module end.


 An unstoppable range of 99 mm on the main line side may vary depending on the pallet length.


Cross section of C


- For details, see the manual .


 Note 10. Design and install the base so that it is within the described tolerance.
- Note 11. When securing the unit using the installation spot facing hole (cross section of C), peel off the dust-proof seal adhered to the inside of the axis, and then install the unit.

2-slider circulation (Note 15)









- Note 12. Reference value for installation of the base. Install the circulation unit so that it is not in contact
- with the base end.

 Note 13. This value may differ from the allowable overhang amount of the robot slider. For details about the payload and allowable overhand amount, see the LCMR200 specifications.

 Even when the circulation operation is performed with workpieces placed, the dimensions are
- restricted in the same manner.
- Note 14. When the pallet length is 200 mm or more, this pitch is "pallet length + 10 mm".

 However, when two sliders start at the same time, the minimum pitch is 250 mm or "pallet length + 50 mm".
- Two-slider simultaneous circulation can be performed only when the movable module is 500mm-module.
- Note 16. The origin position is located on the motor side.


 Note 17. Slider top surface position when the junction axis is stopped by the mechanical stopper.

Circulation pitch	300mm	350mm	400mm	450mm	500mm	550mm	600mm
La	421	471	521	571	621	671	721
Lb	467.8	517.8	567.8	617.8	667.8	717.8	767.8
Lc	300	350	400	450	500	550	600
Ld	200	50	100	150	200	50	100
Le	80	130	180	230	280	330	380
Lf	389	439	489	539	589	639	689
Qa	10	12	12	12	12	14	14
Qb	6	8	8	8	8	10	10
Qc	0	1	1	1	1	2	2
Qd	0	1	1	1	1	2	2
Weight (Kg)(Note 7)	47.6	49.0	50.5	52.0	53.5	55.0	56.4


Circulation unit External view

Vertical circulation

JGX16-V4L/V5L/V6L





JGX16-V5L



- Note 1. For details about the installation and operation procedures, see the user's manual. The user wiring cannot be passed through the flexible cable carrier
- Note 2.
- Do not use the installation hole at each location for an application other than that specified. The robot cable fixing R is R30. The lead-out direction may vary depending on the
- Note 4. specifications.
- The YQLink cable fixing R is R55. This cable may become the termination connector depending on the specifications. Note 5.
- The power cable fixing R is R55.
- The weight of the main body is a reference value. The weights of the module and robot Note 7. slider are not included.
- Note 8. Hexagon socket head cap bolt for fine adjustment of circulation pitch.
- Maintain a work space where you can access the bolt. Robot slider unstoppable range from the module end.
 - An unstoppable range of 99 mm on the main line side may vary depending on the pallet length. For details, see the manual .

JGX16-V6L







Detailed drawing D


- Note 10. Design and install the base so that it is within the described tolerance.


 Note 11. When securing the unit using the installation spot facing hole (cross section of C), peel off the dust-proof seal adhered to the inside of the axis, and then install the unit.
- Note 12. Reference value for installation of the base. Install the circulation unit so that it is not in contact with the base end. Note 13. This value may differ from the allowable overhang amount of the robot slider
- For details about the payload and allowable overhand amount, see the LCMR200 specifications. Even when the circulation operation is performed with workpieces placed, the dimensions are restricted in the same manner Note 14. When the pallet length is 200 mm or more, this pitch is "pallet length + 10 mm"
- However, when two sliders start at the same time, the minimum pitch is 250 mm or "pallet length \pm 50 mm". Note 15. Two-slider simultaneous circulation can be performed only when the movable module is
- 500mm-module. Note 16. The origin position is located on the motor side.
- Note 17. Slider top surface position when the junction axis is stopped by the mechanical stopper.

2-slider circulation (Note 15)










Circulation pitch	300mm	350mm	400mm	450mm	500mm	550mm	600mm
La	421	471	521	571	621	671	721
Lb	467.8	517.8	567.8	617.8	667.8	717.8	767.8
Lc	300	350	400	450	500	550	600
Ld	200	50	100	150	200	50	100
Le	80	130	180	230	280	330	380
Lf	389	439	489	539	589	639	689
Qa	10	12	12	12	12	14	14
Qb	6	8	8	8	8	10	10
Qc	0	1	1	1	1	2	2
Qd	0	1	1	1	1	2	2
Weight (Kg) (Note 7)	47.6	49.0	50.5	52.0	53.5	55.0	56.4

Circulation unit External view

Vertical circulation

JGX16-V1R/V2R/V3R





Detailed drawing B

Grounding terminal (M4) 151.5+/- 1 (Note Power cable (Note 6) YQLink cable (Note 5) 11-M4 × 0.7 through hole 76 113.8 Tap for securing the wiring 259.5 10 (66) 548.6 179 97 6 (69) 94.5 4×4 - $\phi 7.3$ through hole φ11.5 spot facing depth 6 (A in the figure) Spot facing hole for installation of base End plate reference surface 4-M5 × 0.8 depth 12 Tap for installation of module 2-M8×1.25 depth 15 (For installation of eye bolt) 4-Circulation installation plate

JGX16-V1R

JGX16-V2R





- Detailed drawing D
- Note 1. For details about the installation and operation procedures, see the user's manual.
- The user wiring cannot be passed through the flexible cable carrier.
- direction may vary depending on the specifications.


 The YQLink cable fixing R is R55. This cable may become the termination connector depending on the specifications. Note 5.
- The power cable fixing R is R55.
 The weight of the main body is a reference value. The weights of the module and robot slider are not included.
- Hexagon socket head cap bolt for fine adjustment of circulation pitch.
- Maintain a work space where you can access the bolt. Robot slider unstoppable range from the module end.
 - An unstoppable range of 99 mm on the main line side may vary depending on the pallet length.
- Note 10. Design and install the base so that it is within the described tolerance.

- Note 11. When securing the unit using the installation spot facing hole (cross section of C), peel off the dust-proof seal adhered to the inside of the axis, and then install the unit.
- Note 12. Reference value for installation of the base. Install the circulation unit so that it is not in contact with the base end.
- Note 13. This value may differ from the allowable overhang amount of the robot slider.


 For details about the payload and allowable overhand amount, see the LCMR200 specifications. Even when the circulation operation is performed with workpieces placed, the dimensions are restricted in the same manner.


 Note 14. When the pallet length is 200 mm or more, this pitch is "pallet length + 10 mm".
- However, when two sliders start at the same time, the minimum pitch is 250 mm or "pallet length + 50 mm".
- Note 15. Two-slider simultaneous circulation can be performed only when the movable module is 500mm-module.
- Note 16. The origin position is located on the motor side.
- Note 17. Slider top surface position when the junction axis is stopped by the mechanical stopper.


2-slider circulation (Note 15)





JGX16-V3R











Robot cable

(Front lead-out) (Note 4


Circulation unit External view

Vertical circulation

JGX16-V4R/V5R/V6R

JGX16-V4R 4-M5 × 0.8 depth 12 4-Circulation installation plate Tap for installation of module 11-M4 × 0.7 depth 8 /2-M8 × 1.25 depth 15 11-M4 × 0.7 depth 8 (For installation of eye bolt) Tap for securing the wiring 4 × 4-φ7.3 through hole φ11.5 spot facing depth 6 (A in the figure) Spot facing hole for installation of base (63) 179 197 10 + 0.02 depth 11.5 548.6 (63) 48 57 259.5 Detailed drawing B YQLink cable (Note 5) 76 113.8 151.5+/-1 (Note Power cable (Note 6) End plate reference surface Grounding terminal (M4)


JGX16-V5R ab) (19: Base top surface -67 09 9 p Lf +/- 0.5 (Note Qd×200 Qcx200 200 100 126+/-0.02 2 121.5 e l 2-φ 8H7(^{+0.015}₀)depth 10 Spot facing hole for Qb-M8 $\phi 10 H7 (^{+0.015}_{0}) depth 10$ (Note 11) 4 8 (When battery-less absolute is used.) Qa-M8 × 1.25 depth16 Grounding terminal (M4) (40)




- Note 1.
- Note 2.
- Note 3.
- For details about the installation and operation procedures, see the user's manual. The user wiring cannot be passed through the flexible cable carrier. Do not use the installation hole at each location for an application other than that specified. The robot cable fixing R is R30. The lead-out direction may vary depending on the expedifications. specifications.
- The YQLink cable fixing R is R55. This cable may become the termination connector depending on the specifications.
- Note 6.
- The power cable fixing R is R55.
 The weight of the main body is a reference value. The weights of the module and robot slider are not included.
- Note 8. Hexagon socket head cap bolt for fine adjustment of circulation pitch.
- Maintain a work space where you can access the bolt.
- Robot slider unstoppable range from the module end.


 An unstoppable range of 99 mm on the main line side may vary depending on the pallet length. For details, see the manual.
- Note 10. Design and install the base so that it is within the described tolerance.
- Note 11. When securing the unit using the installation spot facing hole (cross section of C), peel off the dust-proof seal adhered to the inside of the axis, and then install the unit.
- Note 12. Reference value for installation of the base. Install the circulation unit so that it is not in contact with the base end.


2-slider circulation (Note 15)



JGX16-V6R







- Note 13. This value may differ from the allowable overhang amount of the robot slider.

 For details about the payload and allowable overhand amount, see the LCMR200 specifications.
- Even when the circulation operation is performed with workpieces placed, the dimensions are restricted in the same manner.

 Note 14. When the pallet length is 200 mm or more, this pitch is "pallet length + 10 mm".

 However, when two sliders start at the same time, the minimum pitch is 250 mm or "pallet length + 50 mm".
- Note 15. Two-slider simultaneous circulation can be performed only when the movable module is 500mm-module.
- Note 16. The origin position is located on the motor side.
- Note 17. Slider top surface position when the junction axis is stopped by the mechanical stopper.

Circulation pitch	300mm	350mm	400mm	450mm	500mm	550mm	600mm
La	421	471	521	571	621	671	721
Lb	467.8	517.8	567.8	617.8	667.8	717.8	767.8
Lc	300	350	400	450	500	550	600
Ld	200	50	100	150	200	50	100
Le	80	130	180	230	280	330	380
Lf	389	439	489	539	589	639	689
Qa	10	12	12	12	12	14	14
Qb	6	8	8	8	8	10	10
Qc	0	1	1	1	1	2	2
Qd	0	1	1	1	1	2	2
Weight (Kg)(Note 7)	47.6	49.0	50.5	52.0	53.5	55.0	56.4



inear conveyor modules LCM

ingle-axis robo

Motor-less single axis actuator Robonity

Compact single-axis robots TRANSERVO

Single-axis robot FLIP-X

Linear motor s single-axis robots PHASER

robots

XY-X

LINEAR CONVEYOR MODULES

LCM100

CONTENTS

■ LCM100 basic specifications ···18
■ Static tolerable load of slider ··· 18
■ Allowable overhang ······18
■ Ordering method······18
■ External view of LCM100 ····18
• Accessory parts ·····18
■ Controller for linear module

■ External view of LCC140 ····190

LCM100 basic specifications





Basic specifica	tions of linea	r conveyor module

Model	LCM100-4M / 3M / 2MT
Drive method	Moving magnet type, Linear motor with flat core
Repeat positioning	+/-0.015mm (single slider) Note 1 /
accuracy	width 0.1mm (mutual difference among all sliders) Note 2
Scale	Electromagnetic type / resolution 5µm
Max. speed	3000mm/sec
Max. acceleration	2G
Max. payload	15kg Note 3 Note 4
Rated thrust	48N
Total module length	640mm (4M) / 480mm (3M) / 400mm (for 2MT circulation)
Max. number of combined modules	16 (total length: 10240 mm)
Max. number of sliders	16 (when 16 modules are combined)
Min. pitch between sliders	420mm
Mutual height difference between sliders	0.08mm
Max. external size of body cross-section	W136.5mm x H155mm (including slider)
Bearing method	1 guide rail / 2 blocks (with retainer)
Module weight	12.5kg (4M) / 9.4kg (3M) / 7.6kg (2MT)
Slider weight	2.4kg / 3.4kg (when the belt module is used.)
Cable length	3m / 5m
Controller	LCC140

Note 1. Repeated positioning accuracy when positioning in the same direction (pulsating). Note 2. Positioning accuracy in the pulsating when using the position correction function with the RFID.

Note 3. Weight per single slider.

Note 4. When used together with the belt module, the max. payload becomes 14kg since

the parts dedicated to the belt are attached to the slider.

Note. Operate LCM100 in the temperature environment (+/-5 °C) that installation and adjustment were performed


Basic specifications of belt module

LCM100-4B / 3B
Belt back surface pressing force driveNote 1
1 guide rail / 2 blocks (with retainer)
560mm/sec
14kg
640mm (4B) / 480mm (3B)
1 slider / 1 module
W173.8mm×H155mm (including slider)
None
Dedicated driver (Included)
DC24V 5A
Dedicated input/output 16 points
11.2kg (4B) / 8.8kg (3B)

Note 1. Because the belt module works on the principle of using the friction of the belt to move the slider, the belt will be abraded and generate dust, making it unsuitable for environments that require a degree of cleanliness.


■ Static tolerable load of slider

Static loads shown below are tolerable as references when performing the screw tightening, part assembly, or light press-fitting on the slider.



FA			(Unit: N)
A ()	Payload		
A (mm)	5 kg	10 kg	15 kg
0	2550	1560	1270
10	1790	1280	1170
20	1380	780	630
30	1130	520	420
40	900	390	310
50	720	310	250
60	600	260	210

Note. The loads shown above are tolerable loads at a position "A"mm away from the center of the guide rail.




10 kg

5 kg

Unit: N)	
κg	
	_

15 k




FC			(Unit: N)
C (mm)	Payload		
	5 kg	10 kg	15 kg
0	1190	850	780
10	970	710	650
20	760	610	560
30	630	530	490
40	540	480	430
50	470	430	390
60	410	390	360

Note. The loads shown above are tolerable loads at a position "C"mm away from the slider upper surface.


Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000 km.

				(Unit: mm)
		Α	В	С
5k	g	677	325	325
10	kg	533	146	146
15	kg	468	90	90



■ Ordering method


Linear module



The above shows "one module + one controller" ordering method. When connecting modules, please separately inform the number of necessary modules.

Note 1. The cable for 2MT has flexible specifications.

Note 2. For 2MT, be sure to select an appropriate network option.



Note 1. Parts necessary to connect the belt module and linear module.


Parts are incorporated into the belt module


Note 2. Perform the bonding with the connection cable that comes from the belt module.





Connection cable (When the termination option L for the belt module is selected.)


Connection cable (When the termination option R for the belt module is selected.)














■ Belt module outline diagram of input/output signal wiring

Connector on front panel

Pin No.	Signal name	Function
A1	+24V	Dower cumby connection DC24\/ (1/400/)
A2	GND	Power supply connection DC24V (+/-10%)
A3	(Blank)	
A4	Option sensor L	Detection output
A5	Option sensor C	Detection output
A6	Option sensor R	Detection output
A7	ALARM	Alarm output
A8	SPEED	Speed output
B1	ALARM-RESET	Alarm reset input ON [L]: Reset OFF [H]: Normal
B2	INT.VR/EXT	Speed setting unit change-over input ON [L]: Internal OFF [H]: External
В3	CW/CCW	Rotation direction change-over input ON [L]: CW OFF [H]: CCW
B4	RUN/BRAKE	Brake input ON [L]: Run OFF [H]: Instantaneous stop
B5	START/STOP	Start/stop input ON [L]: Start OFF [H]: Stop
В6	VRH	(When using the dedicated speed setting unit)
B7	VRM	Minus (-) side DC power supply for speed setting
B8	VRL	Plus (+) side DC0 to 5V, 1mA or more

Note. For each input, a side to be connected to GND by the external switch is ON (L level).

Note. When both the START/STOP and RUN/BRAKE signals are turned ON (L level), the motor starts rotating. In this case, when the CW/CCW signal is turned ON (L level), the slider moves to the left as viewed from the connector side.

Conversely, when this signal is turned OFF (H level), the slider moves to the right.


Note. When the START/STOP signal is turned OFF (H level) in the RUN/BRAKE signal ON (L level) state, the motor stops naturally.

According to the operation speed, the slider may overrun several tens to hundreds of

millimeters.


Note. When the RUN/BRAKE signal is turned OFF (H level) in the START/STOP signal ON (L level) state, the motor stops instantaneously to suppress the slider overrun to its minimal level.

Pin assignment drawing



When investigating the linear conveyor module LCM100 actually, it is necessary to discuss the specifications and restrictions in detail. So, please contact YAMAHA or your dealer to hold hearings regarding your requests.

LCM100/LCC140 Accessory parts



- 1 Module
- ② Robot cable
- 3 Slider
- 4 Termination option (R side)
- (5) Termination option (L side)
- ⑥ Insertion/ejection rail
- 7 Module connection block (with fastening bolts)
- 8 Module connection cable

■ LCM100 main body

LCM100 module



incor	module

	LCM100-4M
	KDJ-M2020-40 (640mm)
Model	LCM100-3M
Model	KDJ-M2020-30 (480mm)
	LCM100-2MT (for circulation)
	KDJ-M2022-20 (400mm)

Belt module

	LCM100-4B
Model	KDJ-4K111-40 (640mm)
Model	LCM100-3B
	KDJ-4K111-30 (480mm)

Robot cable for linear module

Robot cables for the number of modules are required.



	For LCM100-4M/3M
	KDJ-M4710-30 (3m×2 pcs.)
	KDJ-M4710-50 (5m×2 pcs.)
Model	For LCM100-2MT
	KDJ-M4721-30
	(Flexible cable 3m×1 pc.)

KDJ-M4721-50

(Flexible cable 5m×1 pc.)

Slider



Linear module		
Model	KDJ-M2264-00	
Belt module		
Model	KD I-M2264-10	

■ Parts for LCM100

Termination option for linear module (R side)

This part is attached to the right end of the module. One termination module per line is required. Additionally, even when using only one module without connections, one termination module is required.



4

Model KDJ-M2021-R0

Module connection block (with fastening bolts)

This block connects modules. ([Number of modules making up the line Note 1] - 1) blocks are required.

Additionally, when installing insertion/ejection rails, one block per rail is required.



Note. Use this model when installing 100 mm insertion/ejection rails to L side.

Termination option for linear module (L side) This part is attached to the left end of the module.

One termination module per line is required. Additionally, even when using only one module without connections, one termination module is required.



(5)

Model KDJ-M2021-L0

Module connection cable

This cable connects modules. ([Number of modules] - 1) cables per line are required. Note 1



8 KDJ-M4811-00 Model

Insertion/ejection rail

Tapered rail.

Up to two rails per line can be installed. Note 1



44mm: KDJ-M6200-00 (With a dedicated 44mm connection 100mm: KDJ-M2222-10 Model 160mm: KDJ-M2222-20 220mm : KDJ-M2222-30 Note 280mm: KDJ-M2222-40 340mm: KDJ-M2222-50

Note. Not in stock. We require some lead time for delivery.

Note 1. A state, in which multiple modules are connected, is called "line"

■ Parts for LCC140 controller

Power connector + connection lever

One set of parts per LCC140 is required.



HPB dummy connector

When performing the operation with the programming box HPB removed, connect this dummy connector to the HPB connector. One connector per LCC140 is required.



	14514 145400 00
Model	KDK-M5163-00

SAFETY connector

One connector per LCC140 is required.





Not wired (plug + shell kit)

Wired Note

Model

Not wired: KDK-M5370-10 Wired Note: KDK-M5370-00

Note. The wired connector is that the wiring for the emergency stop cancel was performed inside the connector. Select this model when performing the operation check or debugging with single linear conveyor.

■ Parts for line configuration

LINK cable

([Number of modules] - 1) cables per line are required.



	1m : KDK-M5361-10
Model	3m : KDK-M5361-30
	5m : KDK-M5361-50

Terminator connector

When connecting modules, two connectors per line are required.



Model KDK-M5361-00

Dust cover (for LINK connector)

This dust cover is attached to the insertion port, into which the LINK cable terminator connector is not inserted.

When using only one module without connections, two dust covers are required.

Note. The dust cover is essential for the 2MT.



Model KDK-M658K-00 (for MDR20 pin)

■ Selection parts

Proximity sensor for belt module

A sensor for checking the slider position. Install this to prevent slider collisions and to ensure smooth action



R (Right): KDJ-M2205-R0

Programming box HPB/HPB-D

All operations, such as robot manual operation, program input or edit, teaching, and parameter setting can be performed with this programming box.

As an interactive interface with the screen display is used, even personnel who use this programming box for the first time can easily understand how to operate it.

Model	HPB: KBB-M5110-01		
	HPB-D: KBB-M5110-21		
	(CE specifications / with 3-position		
	enable switch)		







Backside of HPB-D (with enable switch)

Support software POPCOM+

PC supporting software POPCOM+



POPCOM+ software model KBG-M4966-00

POPCOM+ environment

os	Windows XP (32bit), Vista, 7, 8 / 8.1,
	10 (Supported version: V.2.1.1 or later)
	Processor that meets or exceeds the suggested requirements for
	the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	50MB of available space required on installation drive.
Disk operation	RS-232C
Applicable controllers	SRCX to SR1, DRCX, TRCX, ERCX, ERCD, LCC140 Note 1

Note 1. LCC140 is applicable to Ver. 2.1.1 or later.

Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

Data cables (5m)

Communication cable for POPCOM⁺. Select from USB cable or D-sub cable.





Model	USB type (5m)	KBG-M538F-00
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10

Note. This USB cable supports Windows 2000/XP or later.

Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.

Note. USB driver for communication cable can also be downloaded from our website.

Reader/writer cable

■ RFID

RFID (manufactured by BALLUFF GmbH)*

Antenna amplifier controller cable

RFID (manufactured by OMRON)



* This cable is a flexible cable

Model 3m: KDK-M6300-00

5m: KDK-M6300-10 10m: KDK-M6300-20 Model 0.5m+2m: KDK-M6300-A0 Dust cover (for RFID)

This cover is attached to the insertion port if RFID is not used. (Included as standard)



Model KDK-M658K-10 (for MDR26 pin)

Whether or not the RFID system can be used may vary depending on the destination place (country). Before selecting a RFID system, please contact YAMAHA.

■ Maintenance parts

Robot cable for LCM100

Lithium battery for system backup

Replacement filter for LCC140 (5 pcs. in package)





	Park Control of the C





Fixed cable Model KDK-M4252-00 KDJ-M4751-30 (3m×1 pc.) KDJ-M4751-50 (5m×1 pc.) Model Flexible cable

Model KDK-M427G-00

Controller for linear module

KDJ-M4755-30 (3m×1 pc.) KDJ-M4755-50 (5m×1 pc.)

LCC140 basic specifications

■ Basic specifications of LCC140 controller Linear conveyor module LCM series Controllable robot **Outside dimensions** W402.5×H229×D106.5mm Main body weight Single-phase AC200 to 230V +/-10% or less (50/60Hz) Input power voltage Maximum power consumption | 350VA (LCM100-4M 1 slider is driven.) SAFETY External input/output RS-232C (dedicated to RFID) RS-232C (for HPB / doubles as POPCOM+) CC-Link Ver. 1.10 compatible, Remote device station (2 stations) **Network option** DeviceNet™ Slave 1 node EtherNet/IP™ adapter 2 ports **Programming box** HPB, HPB-D (Software version 24.01 or later)



