





## B14H RU type (Motor rightward, upper position)



## B14H RD type (Motor rightward, lower position)



## B14H LU type (Motor leftward, upper position)

